



version 1

⚠ Please observe!
Always tighten T-nuts
with a torque wrench.

SMW	Forkardt	Schunk
<p>HFK 160/200 HFKS 160/200 KDV 160/200 KDV 250 KDVG 160/200 KDVG 250 KPV 160/200 KFMM 160/200</p>	<p>2 BLE-PS 160/200 • 2 BLEF 200 KL/KT/KTG/KTN/KS-PS 160/200 KSF 175/200 • KSKL 250 Mo KGH/KGHF/KTH 160/175/200 KS 160/200/250 • KG/KP 200 NH/NHF 160/175/200 QLK/QLC 160/175/200 QLK/QLC-KS 200/250 QLK/QLC-LS 160/200 QLC-AG 200 • UVE 160/200/250</p>	<p>HSL 165/210 TH 165/210 THF 165/210 ROTA NC-D 200 HSG 200 HSG 250 ROTA NC/NCF Plus 165</p>
<p>HFK 250/270 HFK 315 HFKS 250/315 KDV 315/400 KDVG 315/400 KZF 200 • KZF-ES 200 KFMM 250/315 KPV 250/315</p>	<p>3 NH 250-315 • 3 NHF 250-315 KT 250-315 • KSH 250-315 KSHF 250-315 • 3 KTGF 250-315 KG 250-315 • KP 250-315 KLNC 250-315 • KL 250 • KSPS 250-300 3 NHF 290 • KS 315-400 • KSH 400 KSHF 400 • UVE 315 • 3 NHD 400 (Index) 2 BLE 200 • 2 BLE 250 Mo QLK/QLC 250/315 • QLK/QLC-KS 315/400 QLK/QLC-LS 250/315 • QLC-AG 250/315</p>	<p>ROTA NC/NCF Plus 215 ROTA NCO 210 • ROTA NCD 185 ROTA NCK Plus 210/250 • ROTA NCF 165/210 ROTA NC 165/210 • ROTA 2B 160</p> <p>HSL 250/315 ROTA NC-D 250 ROTA NC-O 250 TH 250/315 THF 250/315 HSG 315 ROTA NC-D 315 ROTA NC-O 315 ROTA NCF 315 ROTA NC 315</p>
<p>HFK 400/500 • HFKS 400/500 KDV 500 • KDVG 500 KDS 630 KZF 250 • KZF-ES 250 KZF 315 • KZF-ES 315 KZF 400 • KZF 400-800</p>	<p>3 NH 400-500-630 • 3 NHF 400-500-630 3 KTGF 400-500 • UVE 400-500-630-800 KT 400-500 • KG 400-500 • KL 400-500 KLNC 400-500 • KP 400 • KS 500-630 KSH 500 • KSL 630 • KSHF 630 • KL 300 KSHF 560 • 2 BLE 250 • 2 BLE 315 2 BLE-PS 300 • 2 BLE-PS 315 • 2 BLE 400 2 BLE 500 • 2 BLE-PS 400-500 • QLC 400 • QLK 400</p>	<p>ROTA NCO 260/315 ROTA 2B 200 ROTA NC 250 • ROTA NCF 250 ROTA NC Plus 260/315 ROTA NCK Plus 315 ROTA NCF Plus 260/315</p> <p>HSL 400 ROTA NC-D 400/500 ROTA NC-F 400/500 TH 400/500 THF 400/500 ROTA 2B 250/315/400</p>

T-nuts
 grippers