



version 3

Please observe!
Always tighten T-nuts
with a torque wrench.

Forkardt	Röhm	Schunk
3 KTH 130-33 3 KTH 140-37	KFD 130 • KFH 140 LVE 125 • KFD-HS 160	TP 125 ROTA TP 125 ROTA NCD 165
		TP 160 • ROTA TP 160
		ROTA NCK Plus 165 ROTA NCF 185 ROTA NC / NCF Plus 185
2BLE-PS 160/200 • 2BLEF 200 KL/KT/KTG/KTN/KS-PS 160/200 KSF 175/200 • KS/KL 250 Mo KGH/KGHF/KTH 160/175/200 KS 160/200/250 • KG/KP 200 NH/NHF 160/175/200 QLK/QLC 160/175/200 QLK/QLC-KS 200/250 QLK/QLC-LS 160/200 QLC-AG 200 • UVE 160/200/250		TH/THF/HSL 165/210 ROTA NCD 210 ROTA NC / ROTA NCF Plus 165
		ROTA 2 B 160 ROTA NCD 185 ROTA NC / NCF 165/210 ROTA NCO 210 ROTA NC / NCF Plus 215
	KFD 160/200 • KFD-AF 160/200 KFD-HF 160/200 • KFH-F 160/200 KFH-G 160/200 • KFH-NC 160/200 SPD 160/200 • LVE 160/200	HSG 200/250
3 NH 250/315 • 3 NHF 250/315 KT 250/315 • KSH 250/315 • KSHF 250/315 3 KTGF 250/315 • KG 250/315 • KP 250-315 KLNC 250/315 • KL 250 • KSPS 250/300 • 3 NHF 290 KS 315/400 • KSH 400 • KSHF 400 UVE 315 • 3 NHF 400 (Index) 2 BLE 200 • 2 BLE 250 Mo • 2 BLN 200 QLC 250/315 GHE 250 Mo QLK/QLC-KS 315/400 • QLK/QLC-LS 250/315 QLC-AG 250/315		TP 200 ROTA TP 200 ROTA NC-D 250 HSL 250 TH 250 • THF 250 HSG 315 • HSL 315 ROTA NC-D 315 TH 315 • THF 315 ROTA NCF 315